1	Before driving	1-5.	Refueling Opening the fuel tank cap96
1-1.	Key information	1-6.	Theft deterrent system
	Keys 26		Engine immobilizer system 100
1-2.	Opening, closing and locking the doors		Theft prevention labels (for U.S.A.)104
	Smart access system with push-button start	1-7.	Safety information
	Wireless remote control 42		Correct driving posture 105
	Side doors 46		SRS airbags 102
	Back door49		Front passenger occupant classification system
1-3.	Adjustable components		Child restraint systems 125
	(seats, mirrors, steering wheel)		Installing child restraints 129
	Front seats60		
	Rear seats	2	When driving
	Head restraints	2-1.	Driving procedures
	Steering wheel82		Driving the vehicle142
	Anti-glare inside rear		Engine (ignition) switch15
	view mirror84		Automatic transmission
	Outside rear view mirrors 86		Turn signal lever16
			Parking brake 162
1-4.	Opening and closing the windows and moon roof		Horn
	Power windows 89		
	Moon roof 92		

5

ľ			

2-3.	Gauges and meters	66 171	Utility vehicle precautions. Cargo and luggage Vehicle load limits Winter driving tips Trailer towing Dinghy towing
2 3.	windshield wipers  Headlight switch	87 93 <b>3-1</b> .	nterior features  Using the air conditioning system and defogger
2-4.	washer	00	Automatic air conditioning system
	Cruise control	06 218 25 231 35 241 42	Using the audio system Audio system Using the radio Using the CD player Playing MP3 and WMA discs Operating an iPod <sup>®</sup> Operating a USB memory Optimal use of the audio system Using the AUX adapter Using the steering wheel audio switches

2-2. Instrument cluster

2-5.	Driving information	
	Utility vehicle precautions 2	248
	Cargo and luggage	253
	Vehicle load limits	257
	Winter driving tips	258
	Trailer towing	262
	Dinghy towing	275

## Interior features

system and detogger	
Automatic air conditioning	
system	278
Rear window defogger	
switch	285

Windshield wiper de-icer....... 286

## 3-2. Using the audio system

Audio system	28/
Using the radio	. 291
Using the CD player	. 301
Playing MP3 and	
WMA discs	311
Operating an i $Pod^{ exttt{@}}$	. 321
Operating a USB memory	329
Optimal use of the audio	
system	338
Using the AUX adapter	. 341
Using the steering wheel audio switches	343

3-3.	Using the Bluetooth®	3-6.	Using the storage features	
	audio system  Bluetooth® audio system		List of storage features	.05 .06 .08 410
	Bluetooth <sup>®</sup> audio system setup	3-7.	Other interior features	
			Sun visors	412
3-4.	Using the hands-free phone system (for mobile phones)		Vanity mirrors	
			Clock	414
	Hands-free system for mobile phones		Outside temperature display (vehicles without a navigation system)	416 417
	Security and system setup 389 Using the phone book 393		Seat heaters and ventilators 4	
			Armrest 4	
2 5	Using the interior lights		Coat hooks 4	
J-J.			Floor mat 4	24
	Interior lights list		Luggage compartment features	30 136

4-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior
	Cleaning and protecting the vehicle interior
4-2.	Maintenance
	Maintenance requirements 454
	General maintenance
	Emission inspection and maintenance (I/M)
	programs 460
4-3.	Do-it-yourself maintenance
	Do-it-yourself service
	precautions461
	Hood464
	Positioning a floor jack 465
	Engine compartment 467
	Tires 481
	Tire inflation pressure
	Wheels 494
	Air conditioning filter 496
	Electronic key battery 499
	Checking and replacing fuses
	Headlight aim
	(discharge headlights) 512
	Light bulbs 514

Maintenance and care

## 5 When trouble arises

5-1. Essential information

If your vehicle needs to

Emergency flashers ...... 528

	If you think something is wrong Fuel pump shut off system Event data recorder	537
5-2.	Steps to take in an emergenc	
	If a warning light turns on or a warning buzzer sounds	540
	If a warning message is displayed	550
	If you have a flat tire	569
	If the engine will not start	582
	If the shift lever cannot be shifted from P	584
	If you lose your keys	585
	If the electronic key does not operate properly	
	If the battery is discharged	589
	If your vehicle overheats	592
	If the vehicle becomes stuck	595
	If your vehicle has to be stopped in an emergency	596

6	Vehicle specifications	Index
6-1.	Specifications	Abbreviation list642
	Maintenance data (fuel, oil level, etc.) 598	Alphabetical index644
	Fuel information 610	
	Tire information 613	What to do if
6-2.	Customization	
	Customizable features	
6-3.	Initialization	
	Items to initialize 634	
7	For owners	
	Reporting safety defects for U.S. owners	
	Seat belt instructions for Canadian owners	